UK SET UP INSTRUCTIONS 3728 CHELSEA TWO TIER HEXAGON FOUNTAIN

Open the bag containing the pump kit UK45007. In the kit you will find:

1 - PUMP 450 (12v AC, 50Hz)1 - 2-hole rubber stopper1 - 1/2" kink free tubing 8" long1 - LED light kit (white)

1. Place the pedestal on a firm and level surface where fountain will remain. Place the shell on the pedestal.

2. Find the pump, the LED light kit and the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light kit. Position the 2-hole rubber stopper about 6" from the body of the pump and about 8" from the LED light. On the power cord of the pump there is a Y connection. Attach the plug end of the LED light to the short plug end at the Y connection.

1 - hose clamp

4. Place pump and the LED light in the shell and run the plug end of both power cords down the hole located in the center of the pump house and down through the pedestal. Retrieve both cords from under pedestal and place in the groove in the bottom of pedestal. Pull the remainder of both power cords out from the bottom of the pedestal. Insert the 2-hole rubber stopper snugly into the hole. To make a water tight seal, apply silicone on top and around the rubber stopper. Position the shell on the pedestal and level. To level shell, place level on the top rim of the shell. Level in all directions. Shim as needed.

5. Find the piece of 1/2" kink free tubing 8" long and hose clamp. Attach the 1/2" kink free tubing to the outlet side of the pump with the hose clamp. Insert the LED light head into the opposite end of the 1/2" kink free tubing. Place the pump in the pump house with the tubing assembly facing up

6. Find the finial. In the center of the finial there is a PVC pipe. Remove any excess concrete or tape from both ends of this PVC pipe. Place the finial onto the shell **CAREFULLY** guiding the LED light head up through the center hole. Position the finial in the center of shell.

7. Fill the shell with water. Connect the power cord on the pump to the transformer. Plug the transformer into a 240VAC RCD protected mains outlet. Adjust the water flow using the built in flow control dial on the front of the pump.

UK3728sup 1/30/13