

UK SET UP INSTRUCTIONS

3663 SEVEN TIER GOZO FOUNTAIN ON PEDESTAL

Open the bag containing the pump kit **UK110025**. In the kit you will find:

1 – PUMP 1100 (12vAC, 50Hz)	1 – 2-hole rubber stopper
1 - 27" long piece of 3/4" clear tubing	1 – hose clamp

1. Place the pedestal on a firm and level area where fountain will remain. Place the fountain shell on the pedestal.
2. Find the pump, the 3/4" clear tubing 27" long, the hose clamp and the 2-hole rubber stopper. Attach the piece of 3/4" clear tubing 27" long to the outlet side of pump with the hose clamp. Place the pump in the pump house located in the center of the shell. Run the plug end of the power cord down the PVC pipe located in the pump house and down through the pedestal. Retrieve cord from under the pedestal and place in groove in bottom of pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. **To make a water tight seal, apply silicone in the hole and around the wire that is in the rubber stopper.**
3. Position the fountain shell on the pedestal and level in all directions. **Shim if needed.**
4. Find the drain plug and insert snugly into the drain insert located in the fountain shell. Remove any tape and or dirt from the drain insert before you insert the drain plug
5. Find the round disc spacer. Run the 3/4" clear tubing up thru the center hole and position it on the pumphouse located in the center of the fountain shell.
6. Starting with the largest to the smallest shell, stack and position each shell on the fountain running the 3/4" clear tubing up through the hole located in the center of each shell. Level each shell as stated in step 3.

Each shell is marked with the item number in the center of the shell.

3116S is SHELL #1

3114S is SHELL #2

3113S is SHELL #3

3104S is SHELL #4

3103S is SHELL #5 After you have positioned the shell #5 on the fountain cut the 3/4" clear tubing four inches above the center housing of that shell. Position the last two shells onto the fountain.

3102S is SHELL #6

3101S is SHELL #7

7. Fill each shell with tap water and plug pump into a 240VAC RCD protected mains outlet. Adjust water flow to the statue or finial using the dial type flow control located on the front of the pump until the desired result is achieved.

UK3663sup 8/1/14