

# 2 Tier Barrel Water Feature Instructions



## PREPARATION

Before beginning assembly, please read all warnings and safety precautions.

### WARNING

- To reduce the risk of electric shock, plug-in the pump to a residual current device (RCD) (not supplied).
- Do not exceed the voltage shown on the pump.
- Always disconnect the pump from the power source before performing any maintenance or work on the pump, light(s) or any fountain fittings.
- Inspect the power cord for damage before installation and/or maintenance. Replace the entire pump if damage is found.
- Use a proper power source as indicated on the pump label. Keep the cord away from high temperatures and/or heat sources.
- Do not lift the pump by its power cord.
- Keep the water feature out of reach of children.
- Do not let the pump run dry. Pump must be completely submerged for proper operation and cooling.
- Do not pump hot liquids.
- Operate with freshwater only. Avoid heavily chlorinated water and water with high PH levels.
- Place water feature outdoors on a clean, level surface.
- Store indoors during cold weather periods. Do not operate in freezing weather conditions.
- Only use with the pump / transformer / adapter provided.



## ASSEMBLY INSTRUCTIONS

1. Turn the Small Barrel (5) upside down and screw the Large Panel (4) to it using the screws provided (2).
  2. Connect the tubing to the Pump (8) and place the Pump (8) at the bottom of Large Barrel (6).
  3. Place the Small Barrel with the large panel now attached on top of the Large Barrel (6). Make sure that the electrical cable is fed out the back and the pipe (7) is fed upwards through the barrels. Secure the barrel in place with screws (2).
  4. Screw the Decorative Pump Handle (1) to the base.
  5. Place the Small Panel (3) on top of the water feature, making sure the tubing is fed upwards through the hole. Secure in place using the screws (2).
  6. Connect the tubing (7) to the water pump and screw the water pump into position.
  7. Fill the large barrel with water. The water feature is now ready to be plugged into a power source.
  8. Immerse pump completely in the water with the pump's nozzle above the water level. Ensure the pump is fixed firmly on the bottom of the fountain to avoid vibration.
  9. Plug the connector part of the pump cable into the AC/DC adapter.
- o NOTE: We recommend that you use distilled water to prevent scale build-up. The first time you operate the pump it can take up to 5 minutes for the air to be completely expelled and water to flow properly.

## COMPONENTS

1. 	2. 	3. 
1PC	13PCS	1PC
4. 	5. 	6. 
1PC	1PC	1PC
7. 	8. 	9. 
2PCS	1PC	1PC

1. Decorative Pump Handle (qty x 1)
2. Connector Screws (qty x 13)
3. Small Panel (qty x 1)
4. Large Panel (qty x 1)
5. Small Barrel (qty x 1)
6. Large Barrel (qty x 1)
7. Tubing (qty x 2)
8. Fountain Pump (qty x 1)
9. AC/DC Adapter (qty x 1)



# 2 Tier Barrel Water Feature Instructions



## CLEANING AND MAINTENANCE

**Before beginning assembly, please read all warnings and safety precautions.**

- Make sure all connectors are tight and no water is getting in.
- Keep the water clean during the summer. Keep topping with water every 3 or 4 days with clean water.
- Clean any pipes every month to prevent any build-up of algae which could put extra pressure on your pump.
- Ensure any soil / dirt around the pump is contained and doesn't block the pump.
- Always make sure there is enough water for the pump to work otherwise you could damage the pump. NEVER RUN DRY.
- Make sure you clean the pump on a regularly basis. When you are cleaning, make sure the power is off.
- During the winter, bring the feature inside, give it a good clean and store it safely for next year.

## GUARANTEE

This product is guaranteed against defects in material and workmanship for 12 months from the date of purchase, under normal usage.

The guarantee DOES NOT APPLY in case of improper use, negligence, lack of maintenance or accidental damage to the pump. If the pump fails due to a manufacturing fault within this period it will be either repaired or replaced free of charge. Moving parts or wearable parts including the impeller and any washers or O rings are not covered by the guarantee.

Should your Bermuda product stop working refer first to trouble shooting and if this does not help, return the product to the place of purchase.

Liability is limited to replacement of the faulty product only. No other costs will be reimbursed. This guarantee is not transferable and does not affect your statutory rights.

Do not attempt to tamper with the pump or solar panel. Do not access components inside the pump body, unless otherwise instructed in the instruction manual. Any damage occurred by doing so may invalidate the warranty.

The manufacturer or supplier shall not be responsible, or held liable for any damages caused by defective components or materials of this product, or for loss incurred by interruption of service, or any consequential/incidental damages and expenses arising from the production, sale use or misuse of this product or any other consequential loss.

Any warranty claim must be accompanied by a valid, dated proof of purchase. Evolution Aqua, Bermuda, its distributors and dealers shall not be held liable for any loss of fish, plants or any other livestock as a result of any failure or defect of this product.

The installation and use of your product outside of our recommendations as printed in this manual may also void the warranty.