

UK SET UP INSTRUCTIONS

3861 – 23” TWO TIER BELLA FOUNTAIN

Open the bag containing the pump kit **UK60003**. In the kit you will find:

1 – PUMP 600 (12v AC, 50Hz)	1 – 2-hole rubber stopper	1 - hose clamp
1 – 1/2" clear tubing 2" long	1 – #3 stopper with hole	1 – LED light kit (white)
1 – 1/2" kink free tubing 8" long		

Run the LED power cord through the PVC insert in the top shell first.

1. Find the fountain bowl, the top shell, the pump and the LED light kit. On a padded surface **CAREFULLY** lay the fountain bowl and the top shell in line on their side. In the top, of the top shell there is a PVC insert. Run the plug end and the quick thread nut on the LED light power cord down the PVC insert and out the bottom of the shell. Pull the remainder of the LED light power cord out the bottom of the top shell.

Find the smaller stopper with the single hole and slip it onto the power cord of the LED light about 3 1/2" from the LED light head. Insert the smaller rubber stopper snugly into the PVC insert.

Find the piece of 1/2" clear tubing 2" long and connect it to the 1/2" connection on the LED light head. Connect the opposite end of the 1/2" clear tubing to the copper pipe located in the top shell.

2. Find the 1/2" kink free tubing 8" long and the hose clamp. Attach the 1/2" kink free tubing to the outlet side of the pump with the hose clamp.

3. Find the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light. Position the 2-hole rubber stopper about 8" from the body of the pump and on the LED power cord about 8" from the bottom of the top shell. On the power cord of the pump there is a Y connection. Attach the plug end of the LED light to the short plug end at the Y connection.

4. Inside the fountain bowl there is a PVC pipe. Run the plug end of both power cords, the pump and the LED light, down the PVC pipe and out the bottom of the fountain bowl. Insert the 2-hole rubber stopper snugly into the PVC pipe. Stand the fountain bowl upright. **Be very careful not to stretch the LED light power cord.** Place a piece of padding on the top of the fountain bowl. Place the top shell on the padding that is on the fountain bowl. Retrieve both power cords from under the fountain base and place both in the groove in the bottom of the fountain bowl. Place the fountain bowl on a firm and level area where the fountain will remain.

5. Connect the opposite end of the 1/2" kink free tubing to the copper pipe located in the bottom of the top shell. Position the top shell on the fountain and level. To level, place level on the top rim of the top shell. Level in all directions.

6. Find the drain plug and insert snugly into the drain insert located in the fountain bowl. Remove any tape and or dirt from inside the drain insert before you insert the drain plug. **Add 4" of water in the fountain bowl and fill the top shell.**

7. Connect the power cord on the pump to the transformer. Plug the transformer into a 240VAC RCD protected mains outlet. Adjust the water flow using the built in flow control dial on the front of the pump.