





Power Pub Shed Instructions



Please follow the Power Pent assembly instructions for the Power Pub Shed.


The main difference between the pub shed and our other garden buildings is the roof will have a front overhang:




Power Pub Shed - Component List

	4x4	6x4	8x4	10x4	12x4
2x4 Floor Panel	0	1	0	1	0
4x4 Floor Panel	1	1	2	2	3
2x6 Roof Panel	0	1	0	1	0
4x6 Roof Panel	1	1	2	2	3
2ft Blank Panel	0	2	0	2	0
4ft Blank Panel	2	2	3	3	4
Pub Window Panel	1	1	2	2	3
Door Panel	1	1	1	1	1
Door	1	1	1	1	1
Pub Window Hatch	1	1	2	2	3
4ft Shelving Kit	1	1	2	2	3
4ft Pent Gable Top - Left	1	1	1	1	1
4ft Pent Gable Top - Right	1	1	1	1	1
2ft Pent Front Top	0	1	0	1	0
4ft Pent Front Top	1	1	2	2	3
4ft Bearer	2	2	2	2	2
2ft Roof Extension Piece	2	2	2	2	2
Cover Lats (long)	2	3	3	4	4
Cover Lats (std)	2	3	3	4	4
6ft Pent Bargeboards	2	5	2	5	8
4ft Pent Bargeboards	3	0	6	3	0
600mm Floorboard (treated)	0	6	0	6	0
1190mm Floorboard (treated)	6	6	12	12	18
Felt	2x 4ft roll @ 1M + 4ft @ 0.5M	6x4 roll + 6ft half piece	8x4 roll + 8ft half piece	10x6 roll + 10ft half piece	12x6 roll + 12ft half piece
Fixing pack	1	1	1	1	1
Additional turn buttons	4	4	8	8	12
Additional door pulls	1	1	2	2	3

1. Screw the two gable extension pieces to each side of the roof overhang and screw the tongue and groove boards to the underside of the roof overhang. Please note, the boards may need cutting down to size.



2. To close the pub, the window hatch simply need to be placed into the wall panel from the inside. Turn buttons can be used to secure it in position when the pub is closed.



3. The shelving can be added to the front using the shelving instructions in the booklet provided. Please do not set the shelving too high as it may block the window hatches.

Note - Shelving boards may need cutting down to fit.

