

UK SET UP INSTRUCTIONS

3733 – 71” CHANTICLEER FOUNTAIN

Open bag containing the pump kit **UK110012**. In the kit you will find:

1 – PUMP1100 (12v AC, 50Hz)	1 – 2-hole rubber stopper	1 – putty tape 8” long
1 - 3/4” clear tubing 48” long	1 - tube of silicone	1 – hose clamp

1. Find the pedestal-pump house and position it on a firm and level surface where the fountain will remain. The opening in the pedestal-pump house should face toward back of fountain. Find the pedestal and carefully position it on the pedestal-pump house. On a padded surface, place the largest shell near the pedestal.
2. Find the pump and the 2-hole rubber stopper. Place pump in the center of the large shell and run the plug end of the power cord down the PVC pipe located in the pump house in the center of the shell. Retrieve the power cord from under shell.
3. Run the power cord down the hole that is through the pedestal. Retrieve the power cord from under pedestal and place in groove in the bottom of pedestal. Place the largest shell on the pedestal. While placing the shell on the pedestal carefully pull the remainder of the power cord until all is hidden inside the fountain. Slip the rubber stopper onto the power cord about 20” from the pump. Insert the rubber stopper snugly into the PVC pipe. **To make a water tight seal, apply silicone in the hole and around the wire that is in the rubber stopper.**
4. Position the largest shell on pedestal and level. To level shell, place level on top rim of the pump house in the center of shell and level in all directions. **Shim as needed.**
5. Find the 3/4” clear tubing 48” long and attach one end onto the outlet side of the pump with the hose clamp.
6. Find the second shell and run the 3/4” clear tubing up thru the hole in the center housing of the shell. Position this shell on top of the large shell and level. To level shell, place level on the top rim of the center housing in center of shell and level in all directions.
7. Find the third shell and run the 3/4” clear tubing up thru the hole in the center housing of the shell. Position this shell on top of the second shell and level. To level shell, place level on the top rim of the center housing in center of shell and level in all directions. Check to make sure that the pump is seated on the floor of the pump house in the large shell.
8. Cut the 3/4” clear tubing 6” above the top surface of the center housing of the third shell. Find the putty tape and apply the putty tape around the 3/4” clear tubing and down into the PVC pipe in the top cavity of the third shell. Keep the 3/4” clear tubing in the center of the PVC pipe while you apply the putty tape all the way around. **You want to make a watertight seal so use all of the putty tape.**
9. Find the finial. In the center of the finial there is a PVC pipe, clean any excess concrete or tape from both ends and inside of PVC pipe. Slip the finial onto the 3/4” clear tubing and position the finial on top of fountain.
10. Find the two drain plugs and insert snugly into the drain inserts located in the two larger shells. Remove any tape and or dirt from the drain inserts before you insert the drain plugs.
11. Fill the shells with water. Connect the power cord on the pump to the transformer. Plug the transformer into a 240VAC RCD protected mains outlet. Adjust water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved. Find the square plug and install into the opening in the pump house riser.