



H4944F2RH

Balancing Act Fountain



STAGE 1

Ensure you have all the correct items for your new water feature .



STAGE 2

Lay down some protective material before working on the feature. Locate the threaded nozzle and thread one end into the hole in the bottom of the fountain.



STAGE 3

Locate the black rubber tubing and attach one end to the threaded nozzle, feed the metal clamp over the other end of the tubing, slide halfway down and tighten just enough to hold in place, push the open end of the tubing onto the pump (if the nozzle is too small use the extra one in the accessory bag) feed the power cable over the bowl toward the rear of the fountain.



STAGE 4

Place the single bowl on top of the bottom bowl ensuring the power cable is not trapped anywhere and that the bowl is sat in the correct position. The metal clamp installed in the previous step can be used to control the flow of water.

IMPORTANT - WINTER CARE

Winter Ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:

- Disconnect power to pumps.
- Remove adapter from bottom bowl to open drains and let all moisture out. Keep drains open throughout winter.
- Place an absorbant material like burlap, blankets etc inside vases/bowls and cover all with a fountain cover.
- Do not allow snow or ice to build up on or against the concrete. Remove snow before it turns to ice. Do not use salt or chemical ice removers as these may damage concrete.

ADVISORY NOTICE

HEAVY ITEMS!

Please take care when handling these items