



Assembly Instructions **Cherry Blossom Arch**

Code: 25225

v2




(W x D x H) 2.00m x 0.71m x 2.50m



ONLINE ASSEMBLY VIDEO AVAILABLE

Please scan the QR code or visit zestoutdoorlivingsupport.co.uk



PLEASE KEEP THESE INSTRUCTIONS



Every Zest product is unique because each piece of timber has its own distinctive, natural features.

Zest sources all of its timber from responsibly-managed forests and everything it designs and produces meets the highest standards of sustainability. Zest ensures that all timber and timber-related products are certified to Forestry Stewardship Council (FSC®).

This is vital not only for the health of the planet, but also shows Zest's commitment to the environment and to responsible sourcing. Timber is a natural material and, as such, will fit beautifully within any outdoor space. This also means that all Zest pieces are unique because every piece of timber has its own distinctive features.



Natural and Unique...

Changes in temperature and humidity will cause expansion and contraction so Zest products need time to adjust to where the owners live. A few splits or cracks are part of the maturing process and will not affect strength or durability. Knots embedded in the wood are natural and tell the story of the tree which made them. Customers may notice variations in colour but, once out in the garden and exposed to the sun, colour and shading will even out.

Most Zest products are pressure treated which protects the timber from rot and means customers will be able to enjoy the products in their garden for many years.

Fresh pressure treatment sometimes leads to a small amount of green-spotting on the surface of new timber as the natural salt leaves the wood. This will fade away over time and is in no way detrimental to quality or durability.

Splits and cracks occur naturally in the timber grain due to changing temperatures and humidity levels. They are not usually a cause for concern as they don't affect the strength or durability of the product. If however, a 2p coin can fit into the split or crack there may be an issue so it should be reported to the retailer in writing with photographic evidence.

The benefits of slow grown timber


“ Slow grown timber from Eastern Europe is ideal for timber garden furniture. It produces a stronger grain in the wood giving it more durability and is said to be as strong as some hard woods. ”



Normal splits are characteristics of timber.



Knots are characteristics of timber.



Sun Bleaching & Green Spotting are not causes for concern and they will fade over time when items are placed outdoors.



Should you find a large split or dead knot, please email a photo to your retailer for investigation.

Cherry Blossom Arch Assembly Instructions


Requires: 2 person assembly.

Tools required: Corded / cordless drill, 3mm drill bit as all screw holes need to be pre-drilled,
*Pozi- drive bit /Screwdriver (*Crosshead), Tape measure.

Please take a few moments to check all pack contents listed




Cherry Blossom Arch Pack List			
Code	Item	Description	Quantity
29026	A	POST	4
29025	B	'K' SECTION	2
29024	C	TRELLIS PANEL	3
29023	D	LARGE ANGLED BOARD	2
29628	E	SMALL ANGLED BOARD	2
28101	F	ANGLED BOARD SUPPORT	2

27768 - Cherry Blossom Arch Fixings List		
Item	Description	Quantity
1	50mm Screws	16
2	60mm Screws	24
3	90mm Screws	8





This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase

1



Position 'K' Section (B) 50mm down from the ends of 2x Posts (A) and using 1x Trellis Panel (C) to ensure posts are parallel, attach using 4x 90mm screws as shown.



2



Place 1x Trellis Panel (C) centrally between posts and directly beneath 'K' Section (B) and attach using 6x 50mm screws (1x 50mm screw to each corner and 2x 50mm screws to centre)

Repeat steps 1 & 2 for remaining Posts (A), 'K' Section (B) & 1x Trellis Panel (C)




3



Place 1x Large Angled Board (D) and 1x Small Angled Board (E) centrally onto Angled Board Support (F). Ensure angled boards are flush with ends of Angled Board Support (F) and fix using 4x 60mm screws (2x screws per board).

Repeat for remaining angled boards (D), (E) & Angled Board Support (F)



4



Allowing an overlap of 270mm (nominal) (see Fig. 4a), position 1x board assembly flush to the top of 1x post assembly as shown in Fig. 4b. Ensure angled boards are both parallel with each other and perpendicular to post assembly with equal overlap on both sides. Fix in position using 4x 60mm screws (2x 60mm screws per board).


Repeat procedure at other end of board assembly and remaining post assembly. (See Fig. 4c).

5



Turn main assembly over and repeat instruction 4. (See Figs. 4d & 4e).

6



Place remaining Trellis Panel (C) centrally between Posts (A) and to top of 'K' Sections (B) and attach to 'K' Sections (B) using 4x 50mm screws. (2x 50mm screws per 'K' Section (B)). See Figs. 5a & 5b.



Cherry Blossom Arch is now complete.