











Chopin Pavillion


NR. ART. 041296



 POST	PART: 1 8 pcs
 BOTTOM RING BEAM	PART: 2 8 pcs
 TOP RING BEAM	PART: 3 8 pcs
 ROOF RAFTER	PART: 4 8 pcs
 RAFTERS TIE	PART: 5 1 pc
 ROOF FINAL	PART: 6 1 pc


 RAIL	PART: 7 7 pcs
 TILE	PART: 8 136 pcs
 ANGLE BAR	PART: 9 14 pcs

PART: 10 8 pcs



ROOF PANELS

PART: 11 7 pcs



TRELLIS

PART: 12 16 pcs



CORNER TRELLIS

PART: 13 8 pcs



BELT OF LEAD

EXPLANATION



VIEW









MEASURE



ZOOM




DRAW

PART	FIXING HARDWARE	QUANTITY
A	5,0 x 90 mm 	4 pcs
B	5,0 x 60 mm 	64 pcs
C	4,5 x 50 mm 	106 pcs
D	4,0 x 25 mm 	56 pcs
E	2,5 x 25 mm 	272 pcs
F	2,2 x 50 mm 	112 pcs
	WOODEN SCRIBER	1 pc

STEP 1

SIDE: A



SIDE: B



PART: 1


PART: 1

MEASURE THIS THISTANCE AND DRAW THE CARRYING LINES ON BOTH SIDES: A AND B




REPEAT STEP 1 ON ALL ELEMENTS PART: 1


STEP 2




STEP 3



STEP 4




STEP 5



STEP 6

LIKE IN STEP 2


SEGMENT CREATED IN STEP 5



GROUND MUST BE FLAT
REPEAT STEP 6 – 4 TIMES

STEP 7

LIKE IN STEP 3, 4 AND 5




STEP 8

LIKE IN STEP 5

LIKE IN STEP 7

LIKE IN STEP 7



STEP 9


PART: C

PART: 5


PART: 4

PART: 5


PART: 4




STEP 10




STEP 11




STEP 12




STEP 13



STEP 14




STEP 15



STEP 16

PUT BELT OF LEAD ON ROOF (PART:10)
THEN USE WOODEN SCRIBER TO COMPENSATE LEAD (PART: 13)



REPEAT STEP 16 AROUND THE ROOF

