



# Assembly Instructions

## Clifton Gazebo

Code: 09650

V3




(W x D x H) 2.64m x 2.64m x 2.49m



**ONLINE ASSEMBLY VIDEO AVAILABLE**

Please scan the QR code or visit [zestoutdoorlivingsupport.co.uk](http://zestoutdoorlivingsupport.co.uk)



**PLEASE KEEP THESE INSTRUCTIONS**



# Every Zest 4 Leisure product is unique because each piece of timber has its own distinctive, natural features.

Zest 4 Leisure sources all of its timber from responsibly-managed forests and everything it designs and produces meets the highest standards of sustainability. Zest 4 Leisure ensures that all timber and timber-related products are certified to Forestry Stewardship Council (FSC®).

This is vital not only for the health of the planet, but also shows Zest 4 Leisure's commitment to the environment and to responsible sourcing. Timber is a natural material and, as such, will fit beautifully within any outdoor space. This also means that all Zest 4 Leisure pieces are unique because every piece of timber has its own distinctive features.



## Natural and Unique...

Changes in temperature and humidity will cause expansion and contraction so Zest products need time to adjust to where the owners live. A few splits or cracks are part of the maturing process and will not affect strength or durability. Knots embedded in the wood are natural and tell the story of the tree which made them. Customers may notice variations in colour but, once out in the garden and exposed to the sun, colour and shading will even out.

Fresh pressure treatment sometimes leads to a small amount of green-spotting on the surface of new timber as the natural salt leaves the wood. This will fade away over time and is in no way detrimental to quality or durability.

Splits and cracks occur naturally in the timber grain due to changing temperatures and humidity levels. They are not usually a cause for concern as they don't affect the strength or durability of the product. If however, a 2p coin can fit into the split or crack there may be an issue so it should be reported to the retailer in writing with photographic evidence.

Most Zest 4 Leisure products are pressure treated which protects the timber from rot and means customers will be able to enjoy the products in their garden for many years.

### The benefits of slow grown timber


“ Slow grown timber from Eastern Europe is ideal for timber garden furniture. It produces a stronger grain in the wood giving it more durability and is said to be as strong as some hard woods. ”



Normal splits are characteristics of timber.



Knots are characteristics of timber.



Sun Bleaching & Green Spotting are not causes for concern and they will fade over time when items are placed outdoors.



Should you find a large split or dead knot, please email a photo to your retailer for investigation.

# Clifton Gazebo Assembly Instructions

Requires 2 person assembly


Tools required: Silicone, Silicone gun,  
Corded / Cordless Drill, Pozi-drive Bit / Screwdriver, 3mm Drill Bit required  
in order for you to drill all screw holes before construction.

**Please take a few moments to check all pack contents listed**

<b>Clifton Gazebo Pack List</b>			
<b>Code</b>	<b>Item</b>	<b>Description</b>	<b>Quantity</b>
10894	A	Floor Panel	6
10965	B	Floor Infill	1
10895	C	Post	6
00023	D	Full Panel	1
00024	E	trellis Panel	2
00022	F	Balustrade Panel	2
10897	G	Finial	1
10966	H	Rafter	6
10898	J	Fascia	3
10896	K	Roof Panel	6
10972	L	Roof Panel End Board	6
10967	M	Roof Capping	6
<b>Gazebo Seat Parts - Optional Extra</b>			
11278	N	Leg Brace	12
11279	O	Seat Leg	12
11280	P	Seat Brace	3
11281	Q	Front Fascia	3
11282	R	Back Fascia	3
11283	S1	Seat Board Small	3
11284	S2	Seat Board Medium	3
11285	S3	Seat Board Large	3






11725 - Clifton Gazebo Fixings List		
Item	Description	Quantity
1	45mm Screws	226
2	70mm Screws	73
3	120mm Screws	6
4	Expansion Tape	1







This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase

1



Lay out 6 Floor Panels A as shown in Fig.1a and fix together using 12no 70mm Screws as shown in Fig.1b. Place the Infill B in centre and fix in position using 6no 45mm Screws (Fig.1c).

2



Attach 2no Posts C to Full Panel D using 6no 70mm Screws (3no per post) as shown in Fig.2a. Further attach 2no Trellis Panels E to Posts C using 6no 70mm Screws (3no per post) to form the back wall of Gazebo (Fig.2b).



Attach 2no Posts C to Trellis Panels E using 6no 70mm Screws (3no per post) and fix Balustrade Panels F to Posts C using 4no 70mm Screws – 2no per panel (Fig.2c).

Attach remaining 2no Posts C to Balustrade Panels F using 4no 70mm Screws. Align wall panel assembly with floor panels and fix in position using 15no 70mm Screws – 3no per panel.

See Figs.2d & 2e.




3






Insert 6no Rafter H into predrilled holes of Finial G (Fig.3a) and fix in position using 6no 120mm Screws (1no per Rafter H). Lift Rafter Assembly into slots on top of Posts C (Fig.3b) and fix in position using 12no 70mm Screws (2no per post) – Fig.3c.

4



Fix Fascia J between Posts C above Balustrade Panels F and entrance using 6no 70mm screws (2no per Fascia) – Fig.4.

5





(N.B. Prior to fixing Roof Panels, apply two even beads of silicone to each Rafter D and into grooves in Finial G.)

Position Roof Panel K onto Rafters D and into groove in Finial G (Fig.5a). Fix in position using 6no 45mm Screws (3no per side) - Fig.5b. Repeat procedure for remaining 5no Roof Panels K.






Insert Roof Panel End Boards L as shown in Fig.5c and fix in position using 4no 45mm Screws (2no per side) – Fig.5d. Repeat procedure for remaining Roof Panel End Boards L.

6



Apply Expansion Tape to underside of Roof Capping M (Fig.6a), position over roof panel joint and fix using 6no 45mm Screws (3no per side) – Fig.6b. Repeat procedure for remaining 5no Roof Cappings M.





Using 8no 45mm Screws (4no per Leg Brace N), fix 2no Leg Braces N to 2no Seat Legs O ensuring lower brace is 20mm up from bottom of Seat Legs O and top brace is flush with top of Seat Legs O (Fig.7a). Similarly, build Right Leg Assembly as shown in Fig.7b.

Fix the Back Fascia P (Fig.7c) and Front Fascia Q (Fig.7d) to the two Leg Assemblies using 8no 45mm Screws (4no per Fascia). Locate Seat Brace R between lower Leg Braces and fix using 4no 45mm Screws (2no per side) – Fig.7e.

Fix Seat Boards S1,S2 & S3 as shown in Fig.7f, (ensuring Seat Board S1 is at the front and S3 at the back) using 12no 45mm Screws (4no per Seat Board).

Repeat procedure to build the remaining 2no Seats.

Position completed benches inside gazebo and fix to each other through (upper) Leg Braces N using 4no 45mm Screws – 2no per joint.

Fix bench assembly to posts through rear top corners using 2no 70mm Screws – 1no either end.





**Your Clifton Gazebo is now complete.**