

UK SET UP INSTRUCTIONS

3445 TWO TIER LARGE GIRL HOLDING JUG FOUNTAIN

Open bag containing the pump kit **UK130E**. In the kit you will find:

- | | |
|------------------------------------|----------------|
| 1 – PUMP 750 (12v AC, 50Hz) | 1 – hose clamp |
| 1 - 1/2" kink free tubing 24" long | |

1. Place the pedestal on a firm and level surface where fountain will remain. Position the larger shell on the pedestal and level. To level shell, place the level on the pump house located in the rear of the shell. Level in all directions. Shim as needed.
2. Find the pump, the 1/2" kink free tubing 24" long and the hose clamp. Attach the piece of 1/2" kink free tubing onto the outlet side of the pump with the hose clamp.
3. Place the pump in the pump house located in the rear of the shell and run the plug end of the electrical cord in the groove and over the back wall of the pump house.
4. Find the smaller shell. Run the 1/2" kink free tubing up through the hole in the rear housing that is in the bottom of the shell. Position the shell onto the pump house of the larger shell and level. To level shell, place the level on top of the rear housing located in the rear of the shell. Level in all directions. Shim as needed.
5. Find the finial. On the bottom of the finial you will see a copper pipe. Clean any excess concrete or tape from this copper pipe. Connect the 1/2" kink free tubing to the copper pipe in the bottom of the finial. Position the finial on top of the rear housing of the smaller shell.
6. Find the drain plug and insert snugly into the drain insert located in the shell. Remove any tape and or dirt from the drain insert before you insert the drain plug.
7. Fill the shells with water. Connect the power cord on the pump to the transformer. Plug the transformer into a 240VAC RCD protected mains outlet. Located on the front of the pump there is a dial type flow control. This will regulate water flow to the finial until the desired result is achieved.

UK3445sup 11/13/12