

LIFETIME OUTDOOR SHED EQUIPMENT

10-YEAR LIMITED FACTORY WARRANTY

THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS IF PARTS ARE UNAVAILABLE OR OBSOLETE.

1. Lifetime outdoor sheds are warranted to the original purchaser to be free from defects in material or workmanship for a period of ten years from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to improper installation, alteration or accident. This warranty does not cover damage caused by vandalism, rusting, "acts of nature" or any other event beyond the control of the manufacturer.
2. This warranty is nontransferable and is expressly limited to the repair or replacement of defective product. If the product is defective within the terms of this warranty, Lifetime Products, Inc. will repair or replace defective parts at no cost to the purchaser. Shipping charges to and from the factory are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the shed or its components are not covered under this warranty.
3. This warranty does not cover scratching or scuffing of the product that may result from normal usage. In addition, defects resulting from intentional damage, negligence, unreasonable use or hanging from the truss will void this warranty.
4. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in all equipment, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.
5. This product is not intended for institutional or commercial use; Lifetime Products, Inc. does not assume any liability for such use. Institutional or commercial use will void the warranty.
6. This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to extent permitted by Federal and state law. Neither Lifetime Products, Inc., nor any representative assumes any other liability in connection with this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

ALL WARRANTY CLAIMS MUST BE ACCOMPANIED BY A SALES RECEIPT.

REPORT PRODUCT DEFECTS IN WRITING TO:

Lifetime Products, Inc., PO Box 160010 Clearfield, UT 84016-0010
or call (800) 225-3865 M-F 7 a.m. to 5 p.m. MST.

Please include your dated sales receipt and photographs of damaged parts.

To register the product, visit our Web site at www.lifetime.com



www.lifetime.com

©2004 Lifetime Products, Inc.

PO Box 160010 • Freepoint Center, Bldg. D-11 Clearfield, Utah 84016-0010
T: 800-225-3865 • F: 801-728-1907

OWNER'S MANUAL *with Assembly Instructions*



8'x10' Outdoor Storage Shed



**Lifetime
8' x 10' Outdoor Shed
MODEL #6419**

REGISTER YOUR LIFETIME PRODUCT TODAY!

There are benefits to registering your Lifetime product. With our new online product registration form, it's fast and easy! Register with us at www.lifetime.com and enjoy these great benefits:

- Receive exclusive money-saving offers from BuyLifetime.com, our online store, as well as NEW product notifications and special closeout promotions!
- In the unlikely event of a product recall or safety modification, we will notify you immediately and directly.
- Registering your product guarantees you warranty service. If you do not register your product, your warranty rights will not be diminished. But you will need to provide a sales receipt to verify your product purchase date before warranty service will be provided.

Lifetime's Promise to You:

Maintaining your privacy is our long-standing policy at Lifetime. And you can rest assured that Lifetime will not sell or provide your personal data to other third parties, or allow them to use your personal data for their own purposes.

We invite you to read our privacy policy at www.lifetime.com

REGISTER today!

Level Surface Notice:

Surface must be leveled before installation. We recommend building a level work space with a cement or patio style surface. If the surface is not properly leveled, the Outdoor Shed will not assemble correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.

Building Code Notice:

Consult all local building codes, as well as city and county ordinances, to ensure that the construction of the Outdoor Shed does not require a building permit. Proper building permit documentation may be required in your neighborhood, and it would be unfortunate to learn this after constructing the Shed.

Screwdriver Notice:

There is a 1/2" Phillips head screwdriver bit included with the shed hardware. This bit can be used with any power screwdriver or drill. The plastic pieces of your shed can be damaged by overtightening of screws. To avoid damage we strongly recommend the use of a low-powered power screwdriver or a drill that has an adjustable clutch that is set on a low torque setting. If neither is available, use a hand screwdriver. In any case, use caution to avoid overtightening the screws.

Floor Puncture Notice:

Sharp objects may damage your floor. If resting sharp, heavy objects on your shed floor, place a block of wood between the sharp object and floor.



SAFETY INSTRUCTIONS



FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

To ensure safety, do not attempt to assemble this shed without following the instructions carefully. Check entire box and inside all packing material for parts and/or additional instruction material. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use and supervision are essential for proper orientation and to reduce the risk of accident or injury.

- Do not use or store hot objects such as grills, blowtorches, welding equipment, etc. in the shed.
- If using a ladder during assembly, use extreme caution.
- Two capable adults are required for shed assembly. (It is also recommended that a third adult function as an instruction reader.)

Most injuries are caused by misuse and/or not following instructions. Use caution when using this shed.

25.2: Peel off the backing from the short piece of Weather Stripping (AO) to expose the adhesive edge. Open both Doors and attach the Weather Stripping along the outside edge (Grayed Area) of the Front Gable as shown. When closed, the Doors should contact the Weather Stripping.




Exterior Upward View

Apply Weather Stripping (AO) here.



25.3: Peel off the backing from the longer pieces of Weather Stripping (AN) to expose the adhesive edge. With the Doors open, attach the Weather Stripping down along the inside edges (Grayed Area) of the Wall Panels as shown. When closed, the Doors should contact the Weather Stripping.



Apply Weather Stripping (AN) here.

Interior Outward View

Enhance your Lifetime® Outdoor Shed by purchasing the following Shed Accessories:

Modd #


- 0110** Corner Shelf (2 pack)
Two 10" radius Shelves with hardware.
- 0130** 32" Shelf Kit w/ hardware (3 pack)
Three 32" x 10" Steel-Reinforced Shelves with shelf brackets and hardware.
- 0150** 8' Shelf Kit w/ hardware
One 96" x 9" Steel-Reinforced Shelf with shelf bracket and hardware.
- 0170** Pegboard w/ hardware
One 22.5" x 22.5" Pegboard Panel with hooks. Great for hanging large and small items such as: rakes, shovels, and hand tools.
- 0190** Shelf Support Channel
Two Shelf Support Channels that allow the 32" shelves on either of the side walls of your shed.
- 6420** 30" Shed Extension Kit
Extend your shed two and a half feet for the ultimate storage building.




0110



0130



0150



0170




6420

To purchase shed accessories, visit us at:
www.buylifetime.com
Or call: 1 (800) 424-3865


24 Insert Gable Clips in Back Wall

24.1: Insert the Gable Clips (TF) into the back Wall Panels as shown.





25 Weatherproofing the Shed

25.1: Use the Caulking (AP) provided to seal the Floor of the Shed. Apply a 1/4" bead of Caulking around the entire perimeter of the Shed, at the seam between the Wall Panels and the Floor. Smooth with a damp cloth.




Apply a 1/4" bead of Caulking at the seam between each Wall Panel. The bead should run from the bottom screw location down to the Floor. Smooth with a damp cloth.



Front of Shed

Apply a 1/4" bead of Caulking at the seam between each Wall Panel and the Front Gable. The bead should run between the Gable and the top of the Corner Panel on both sides of the Door. Smooth with a damp cloth. Repeat at same locations for the Rear Gable.



STOP!

Read This First!

STOP!

Before Beginning Assembly:

- Read the "Congratulations" letter on pages 4-5.
- Remove Parts List from the center of these instructions and make sure all parts are present and in good condition.
- Find the color "Construction Tips" flyer and refer to it during assembly.

****Do Not Contact the Store!****
For Assistance, including missing or broken parts,
Call Customer Service at:
1 (800) 225-3865

*** Customers outside of the U.S. or Canada, please contact the store for assistance. ***

KEY



Indicates a helpful hint or important note.



Indicates that a hand screwdriver is required for a step.



Refers you to a specific step in the full-color Construction Tips flyer.



Caution: If more than six (6) inches of snow accumulate on the roof of the shed, carefully remove the snow to avoid possible roof collapse. While standing on the ground, remove the snow from the roof with a broom or snow shovel. Do not stand on the roof to remove snow.

Congratulations on your Lifetime® Outdoor Shed purchase. By following the instructions below, your new Lifetime shed should provide you with years of service and enjoyment.

Cleaning and Care

The polyethylene walls and shelves are stain- and solvent resistant. To clean, use a mild soap and a soft-bristled brush. Abrasive cleaning materials may scratch the plastic and are not recommended. Repair scratches or rust spots on the metal by sanding the affected area lightly; using a rust preventative spray primer, and finally, spraying with a high-gloss spray enamel paint. Avoid placing a direct heat source on or near surfaces unless using a heat barrier.

IMPORTANT! Please Read

Dear Valued Customer,

We would like to congratulate you on your purchase of a Lifetime® Outdoor Storage Shed! We are confident that you have made the perfect choice and you will be very pleased with your new storage solution.

This Outdoor Storage Shed is part of the family of brands created and manufactured by Lifetime® Products, Inc. Like all of our products, you can be assured that the quality of your Lifetime Outdoor Storage Shed is the best in the world! All of our sheds are made in the USA, something that is very important to us. And, we back that quality up by offering the best warranty in the business – A 10-year warranty that covers everything on the shed... top to bottom!

All of our sheds are built with the highest-quality steel and polyethylene parts. The design and construction of our steel-reinforced double-wall panels is second to none. All of our exposed steel parts and trusses are powder coated and we only use high-impact polyethylene plastic. What makes polyethylene so special? It has superior strength and durability, and, it won't crack or degrade outdoors.

So now that you know the quality you are getting in a Lifetime® Outdoor Storage Shed, please take the time to READ THIS INSTRUCTION MANUAL!

We have taken great care in providing the best possible form of instructions to help you put your new Outdoor Storage Shed together. Before you get started, PLEASE read the following preparation tips to help you get started!

We can assure you, your construction experience will be a lot more enjoyable if you do!

PREPARATION TIPS:

- The first step is simple... RELAX! You have made a great purchase, but Rome was not built in a day. Plan to spend a good part of your weekend putting together your fine Outdoor Storage Shed. Our philosophy is, if it comes together quickly and easily, it surely will come apart quickly and easily! Your Lifetime® Outdoor Storage Shed will surely last for years if you are patient, and take all the time necessary to put it together as we have instructed.
- Grab a friend to join in on the fun! This is not a one-person endeavor. We have found that not only will things go smoother if you have two or more people participating in the construction of the shed, but it will go quicker as well. So, the more the merrier!
- Make sure you have all the tools necessary for constructing your new shed. We have included a 1/2" Phillips head screwdriver bit that may be used with any power screwdriver or drill. This bit is your friend... please use it. The plastic pieces of your shed may become damaged by overtightening the screws. To avoid this damage, we strongly recommend the use of a low-powered power screwdriver or a drill that has an adjustable clutch that is set on a low-torque

- 1 -



22 Anchor the Shed

22.1: After assembling your shed, you will need to anchor it to the ground through the four indentations in the shed floor. Consult your local hardware store for suggestions on the best hardware to use for anchoring your shed.



23 Install Gap Flaps on Doors

23.1: Install the Gap Flaps (FA & FB) inside each door as shown. Before completely tightening Screws (LA), slide Flap up until it covers any gap between the top of the Door and the Gable.



20 Shelf Installation

20.1: Insert Shelf Brackets into notches below the 90° Shelf. Place Short Shelves (126) on Brackets and secure with Screws (SS).





NOTICE

The total weight placed on shelves hung on each Wall Panel cannot exceed 100 pounds (45 kg).




Hardware Bag: #2 Screwdriver (1)
1001632



Shelf Support Channels can also be installed in the Window Wall Panel, as shown.

Additional Shelf Locations

Additional shelves and Support Channels can be purchased from Customer Service. These shelves and Support Channels can be installed on any wall containing a truss notch and a column of screw holes.



Additional Shelves and parts can be purchased from Customer Service:

1 (800) 225-3865

** Customers outside of the U.S. or Canada, please contact the store for assistance. **

21 Align Doors

21.1: In some cases, the shed doors may not completely line up at the tops (fig. 1). When this happens, identify which side is higher and use a Wooden Shim (BD) to slightly raise the back corner of the high side until doors line up (fig. 2). If doors need further adjustment, insert another shim under the front corner opposite of the first shim. If the doors still need further adjustment, stack additional shims (one at a time) alternating between the back and front shims.



Fig. 1



Shim should be placed at the corner, running directly under one wall.




Fig. 2

After doors are aligned, cut off any portion of wood shim that is still exposed. From inside the shed, drive a 1" nail through the floor into the shim to hold it in place.

setting. If neither is available, use a hand screwdriver. If a hand screwdriver is all you have, take several breaks... your wrist will need it!

- You will also need two small step ladders (when it comes time to do the roof), a 7/16" wrench and a 3/8" wrench.
- The small wood block in your shed box is there for a reason. DO NOT THROW THE WOOD BLOCK AWAY, it is necessary for attaching the wall panels to the floor.
- Read through the entire instruction manual and "Construction Tips" insert before you start. It's always a great practice to get a feel for the flow of the process and to familiarize yourself with the parts involved. But, try not to get ahead of yourself and start the process out of order.
- FOLLOW THE INSTRUCTIONS IN ORDER! Everything goes together in a certain order, and we have learned what that correct order should be. In our state-of-the-art research and testing facility, we have painstakingly created these instructions. The order of construction is there for a reason, and some parts simply will not fit if built out of order. Just follow along with the order in the instructions and everything will fit together and things will go very smooth.
- Refer to the color "Construction Tips" insert for the trickier construction spots. We have identified a few places during construction where it can get a bit tricky, that is why we included the color insert. This full-color instruction extra was created to better guide you through the process. Use it and you will be a much happier Outdoor Storage Shed builder.
- YOUR SHED MUST BE BUILT ON A LEVEL SURFACE! If the spot you have chosen to place your wonderful new Outdoor Storage Shed is not level, the shed will not assemble correctly! We recommend a level cement or patio style surface. Your shed is meant to last a long time, so provide the proper foundation for it before you start to build.
- Before you build it, make sure you are allowed to build it! Consult all building codes, as well as city and county ordinances, to ensure that you do not require a building permit to construct your Outdoor Storage Shed. Proper building permit documentation may be required in your neighborhood, and it would be quite unfortunate to learn this after your Outdoor Storage Shed is already built!

Now that you're ready to begin the construction of your wonderful new Outdoor Storage Shed, step back, take a deep breath, get yourself a large cold beverage and enjoy yourself. We guarantee that after spending the right amount of time in building your shed, you will be able to enjoy it for years to come.

Thanks for choosing Lifetime® Outdoor Storage, and have fun!



1 Site Selection

1.1: The actual dimensions of your shed (at its widest and longest points) are 8' x 10'. Ensure you select a site that will accommodate these measurements. The base of the shed is slightly smaller than this, so you will need to create a level surface that is at least 93.5" x 118.25". We recommend using a level cement or patio style surface. This will provide the best long-term performance for your shed.



NOTICE: Shed Extension Kits are available for this shed. Please consider possible shed expansion when planning the site for your shed. See inside the back cover of this manual for information on ordering Extension Kits.

Surface must be leveled before installation. If the surface is not properly leveled, the outdoor shed will not assemble or function correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.


Alternate Site Preparation

Wherever possible you should use the surfaces described above. When this is not possible, we recommend you use one of the following options:

Note: Any platform or similar structure should be built above ground in order to avoid water pooling inside shed.


OPTION 1: Wood Platform

Be sure you use lumber that is treated and approved for outdoor use. Build outside frame to 93 1/2" x 118 1/4" outside dimensions:



Item	Qty.
2" x 4" x 90 1/2" treated board*	8
2" x 4" x 118 1/4" treated board*	2
48" x 93 1/2" Plywood (ACX)**	2
22 1/4" x 93 1/2" Plywood (ACX)**	1
16d 3" common nails	32
8d 1 1/2" common nails	36

* All lumber must be rated for outdoor use.
** Trim 4' x 8' sheets to this size.



To be sure to have studs in the correct location to nail plywood in the next step, start measuring here & measure from center to center.

Place the 2" x 4" x 90 1/2" boards on the inside of the frame. Nail each board in place with the 16d nails.

18 Skylight Installation


18.1: Pre-fold Skylights (A,J) before installing.



Hardware Bag: #2 Screwdriver (1) HH11600

18.2: Push folded Skylight up through opening; open Skylight; use tabs to pull Skylight down into place.

18.3: Fasten Skylight in place with Washers (LB) and Screws (LA) (pull on tabs to provide resistance while inserting screws).




Repeat for all Skylights.



19 Pegboard Installation

19.1: Use a Level, and position both 16" Pegboard Strips (AK) in the desired locations. Fasten the Pegboards to the Wall using #10 x 3/4" Screws (PB). See Note.

Hardware Bag: #2 Screwdriver (1) 1011398, 1029336 Level



The Pegboard Strips are screwed directly into the plastic. Line up Strip anywhere on wall so holes are over plastic (and not over a groove in the wall).

Be sure that the Pegboard Strip is level before inserting screws.



19.2: Insert the Tool Clips (CA, CB, CC, CD, CE) into the Pegboard Strip.


17.15: Position and secure Center Roof Cap (117) along Truss.



SS (12)

Hardware Bag: 1001632


Screwdriver (1)



17.16: Connect centers of Roof Caps (117).



Only use a hand screwdriver on this step





CAUTION
Only hand tighten screws in Roof Caps. Do not overtighten. Overtightening may damage Roof Caps and void warranty.

17.17: Position and secure Rear Roof Cap (116) along Rear Gable.



17.18: Connect Rear & Center Roof Caps.



Square up the frame by measuring from corner to corner. Measurement A should equal Measurement B.



Line up a large sheet of outdoor rated plywood (48" x 93.5") with the end of the frame (same end you measured from). Nail plywood in place.

Place next large sheet. Cut last sheet of plywood to fit remaining space (22"x93.5") on frame. Nail plywood in place.

Place platform in the desired location. If platform does not rest level on the ground, build up low points with loose dirt until platform is stable.

Drill 3 evenly spaced 1/2" drain holes in plywood between each 2" x 4" joist.


OPTION 2: Filled Wood Frame

Be sure you use lumber that is treated and approved for outdoor use. Cut outside frame to 8" x 10' outside dimensions:


Item	Qty.
2" x 6" x 7' 5" treated board*	2
2" x 4" x 10' treated board*	2
8d 1 1/2" common nails	16
1" L' bracket	4
*"Pea" gravel	9.8 cu. ft. (approx.)
Leveling board (2" x 4" x 10')	1

* Must be rated for outdoor use

Be sure that frame is level.



Nail an L-bracket on each corner of the frame with 8d nails.



Square up the frame by measuring from corner to corner. Measurement A should equal Measurement B.

Place platform in the desired location. If platform does not rest level on the ground, build up low points with loose dirt or "Pea" gravel, until platform is stable.



Once all boards are level and do not wobble, pack "Pea" gravel or dirt around the outside of the frame, and slope away from frame.



Use approx. 9.8 cu. ft. of "pea" gravel.

Now fill the inside of the frame with "Pea" gravel. Use a leveling board to scrape off extra fill material and to level the surface.

Before Beginning!

Remove the Parts List from the center of this manual, and locate color "Construction Tips" insert in box.


2 Assemble Floor

2.1: Lay Outer Floor Panel (109) flat on the ground. Hold a Center Floor Panel (110) at an angle (as shown) and fit tabs into slots and lay Center Floor Panel flat. Add next Center Panel (110) and last Outer Panel (109).



CAUTION


Sharp objects may damage your floor. If resting sharp, heavy objects on your shed floor, place a block of wood between the sharp object and floor.



3 Assemble Window


3.1: Remove plastic sheeting from Window (AA) and slide Window into slot on the Window Wall Panel (125). Attach a Window Latch (HQ) above each corner of the Window as shown. When tightening Screws (SS), be sure that Window Latches will slide freely.

3.2: Do not overtighten. Insert Screw (TC) into the hole in the window.




Hardware Bags:
1001632 1033420

Screwdriver



Place Screw (TC) in this hole to keep window from sliding up too far. Insert until flush with the window

17.13: Install next Roof Panel for Domed Skylight and Roof Supports.




(Not actual size) AI (3)







Hardware Bag: 1001632 Screwdriver

Note: Use one (1) Roof Support (AU) for a regular Roof Panel and two (2) Roof Supports (AU) for the Roof Panel for Skylight.



Note: The holes in the Roof Support Strips are for manufacturing purposes only.


17.14: Install last Roof Panel and Roof Support.



17.10: Connect centers of Front Roof Cap (115) and Roof Cap (117) with Screws (SS).



Only use a hand screwdriver on this step




(Not actual size) AI (2)
SS (36)

Hardware Bag: 1001632 Screwdriver

CAUTION


Only hand tighten screws in Roof Caps. Do not over-tighten. Over-tightening may damage Roof Caps and void warranty.

17.11: Install the next Truss, two Roof Panels (114) and Roof Cap (117).




Note: The holes in the Roof Support Strips are for manufacturing purposes only.

17.12: Install Rear Gable assembly.



4 Assemble Front Corner

4.1: Fit Left Front Corner Panel (105). Fit tabs of panel into the front left corner (white facing shed) of your floor. Place a Wood Block (BC) under floor panel, directly under first tab, then pull down on Corner Panel until tab snaps into place. Move block under the next tab and repeat.



Place Wood Block (BC) directly under the tab you are inserting. Snap tabs into place one at a time.




5 Assemble Left Wall

5.1: Snap Wall Panels (108) into place along the long side of shed. Window Wall Panel (125) can be inserted into any side Wall Panel position. Ensure holes line up and then fasten panels together with Screws (SS).

SS (15)

Hardware Bag: 1001632 Screwdriver



Place Wood Block (BC) directly under the tab you are inserting. Snap tabs into place one at a time.





Second person should apply pressure on opposite side of the wall for easy insertion of screws.


Do Not Over-Tighten Screws



5.2: Fold Left Back Corner Panel (107). Snap into place and fasten with Screws (SS).



Hardware Bag: 1001632 Screwdriver



Place Wood Block (BC) directly under the tab you are inserting. Snap tabs into place one at a time.

6 Assemble Back Wall

6.1: Insert two Wall Panels (108) along back side of shed. Ensure holes line up and fasten panels with Screws (SS).

Do Not Over-Tighten Screws



Second person should apply pressure on opposite side of the wall for easy insertion of screws.


1.




2.



Hardware Bag: 1001632 Sawdriver



17.7: Install next Truss.



(Not actual size) AI (2)



Hardware Bag: 1001632 Screwdriver


17.8: Follow steps 17.2 - 17.4 to place the next Roof Panels (114) and Roof Supports (A1). Repeat for other side.




Note: The holes in the Roof Support Strips are for manufacturing purposes only.



17.9: Position Roof Cap (117) next to Front Roof Cap. Attach to Truss with Screws (SS).



17.5: Follow steps 17.2 - 17.4 and install a Roof Panel and Roof Support on opposite side.




(Not actual size) AI (1)




Hardware Bag: 1001632 Screwdriver

Note: The holes in the Roof Support Strips are for manufacturing purposes only.

17.6: Position the Front Roof Cap (115) as shown. Secure to Front Gable with Screws (SS).



6.2: Fold Right Back Corner Panel (106). Snap into place and fasten with Screws (SS).




Hardware Bag: 1001632 Screwdriver



Place Wood Block (BC) directly under the tab you are inserting. Snap tabs into place one at a time.

7 Install Back Shelf

7.1: Insert a Shelf Support Channel (AF) into the slot directly below the Right Truss Notch, and secure with Screws (SS) beginning at the bottom of the Channels and working up. Insert a second Shelf Support Channel (AF) in the position shown in Fig. 1, and secure with Screws (SS). Set a Shelf Support Bracket (AE) into the top location of each of the Shelf Support Channels.



Hardware Bags: 1001632 Screwdriver




Start at the bottom of the channel to insert screws.



Insert Bracket at an angle.

Left Truss Notch
Insert Channel Here.
Right Truss Notch



7.2: Fold up flaps on end of 90" Long Shelf (120). Set shelf on brackets with indentations toward wall, and Screw (SS) into place.



There are only holes for screws along front side of the shelf (front is labeled "Front" on underside of shelf).



Hardware Bag: 1001632 Screwdriver

8 Assemble Right Wall




8.1: Snap Wall Panels (108) into place along long side of shed. Ensure holes line up and fasten panels together with Screws (SS).

If you haven't inserted the Window Wall Panel (125) yet, you can insert it into any of these side Wall Panel positions.

Do Not Over-Tighten Screws



Second person should apply pressure on opposite side of the wall for easy insertion of screws.



Hardware Bag: 1001632 Screwdriver


17.3: Secure the Roof Panel to the Front Gable and Truss Channel with all but the very top Screws (SS). Slide the Roof Supports (AI) into place between the Roof Panel and Gable/Truss. Insert top Screws (SS).



Use a flashlight to check that holes line-up before inserting screws.



Only use a hand screwdriver on this step



The Roof Support fits into the notches in the Roof Panel (as shown).

(Not actual size) AI (2)



Hardware Bag: 1001632 Screwdriver

A second person on a ladder should apply downward pressure while attaching roof parts.

17.4: Bottom lip of Roof Panel fits over Wall Panel and ridge fits into the top of the wall. Secure the roof panel along the bottom edge with Screws (SS).

Be sure the ridge in the bottom of the Roof Panel fits into the top of the wall.



Roof Panel Ridge

Roof Panel


Wall

Note: The holes in the Roof Support Strips are for manufacturing purposes only.



17 Truss & Roof Installation

17.1: Place a Truss into the first set of notches behind the Front Gable.




Be sure to carefully read and follow the roof installation instructions and notes. Following each step in the order listed will minimize potential complications during installation.

Caution: If more than six (6) inches of snow accumulate on the roof of the shed, carefully remove the snow to avoid possible roof collapse. While standing on the ground, remove the snow from the roof with a broom or snow shovel. Do not stand on the roof to remove snow.



17.2: Place a Roof Panel for Domed Skylight (AL) onto the Truss and the Front Gable. Be sure the alignment nub in the roof panel fits into notch on the truss.



Be sure the nub in the Roof Panel fits into the notch in the Truss.




8.2: Fold Right Front Corner Panel (104). Snap into place and fasten with Screws (SS).



Place Wood Block (BC) directly under the tab you are inserting. Snap tabs into place one at a time.

9 Install Corner Shelf





9.1: Fold up edges of Corner Shelf (121). Line-up holes in Corner Shelf with top set of pre-made holes in Right Front Corner Panel and secure with Screws (SS). Repeat this step for the Left Front Corner.



Corner Shelf should only be placed in top set of holes. See inside the back cover for information on purchasing additional shelves.

10 Left Door Assembly

10.1: Rest Left Door (118) with front side down. Position Deadbolt Latches (HM) in slots at top and bottom of door then slide Door End Channel (AG) onto the door.




Door End Channel fits onto door with the flat side up (facing the Dead bolt Latches).


10.2: Slip the Strike Plate (HT) over the Left Door and align the holes.



10.3: Attach the Left Door Latch (HP) to the Strike Plate with two (2) Carriage Bolts (HC) and two (2) Cap Nuts (HL).



10.4: Attach the Left Door Handle (BB) using three (3) Washers (VC) and three (3) Screws (PB).





CAUTION
Do not overtighten. Overtightening may damage parts and void warranty.

WARNING
Do not overtighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.



You may need to nudge the Door End Channel to make the holes line up with the gap in the door.

16.3: Remove the protective plastic film from the Domed Skylight (AM). Position the Domed Skylight over the opening in the Roof Panel for Domed Skylight so the angled edge is at the top, then place the Domed Skylight on the Roof Panel. Press down and verify there are no gaps or bubbles between the Butyl Tape and the Domed Skylight.




Note: The sticker indicates the top and exterior side of the Domed Skylight.

16.4: Insert one (1) #10 x 5/8" Carriage Bolt (DA) through each hole in the Domed Skylight, press the Bolt through the Butyl Tape and through the Roof Panel for Domed Skylight.



16.5: Secure the Domed Skylight to the Roof Panel with a #10 Washer (VC) and #10-24 Cap Nut (HK) for each Carriage Bolt. Set Skylight/Panel Assembly aside. Repeat 16.1 - 16.5 for the Second Domed Skylight and Panel.



WARNING
Do not overtighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.


15.3: Slide a Threaded Rod (SA) through the Truss Support Brace and the top of the Truss Connector.



15.4: Secure the top and bottom of the Threaded Rod with a 1/4" Cap Nut (HL).



15.5: Repeat Steps 15.1 - 15.4 for each Truss.




WARNING
Do not overtighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.

16 Domed Skylight Assembly

16.1: Cut the Butyl Tape (BT) into four equal pieces (about 3' x 1 1/2"). Carefully apply one piece of Butyl Tape over the holes along the groove (grayed area) around the opening of the Roof Panel for Domed Skylight. Lay sticky side down. Lay a second piece over the holes along the second half of the groove. Ensure the two pieces overlap on both ends and cover the holes.

16.2: Press down on the Butyl Tape to help remove any gaps or bubbles between the Butyl Tape and the grooves in the Roof Panel. Remove the paper backing from the tops of the two pieces of Butyl Tape.




Note: Use a screwdriver to remove any excess plastic from all holes in Panel.

Important: Butyl Tape must cover all twelve holes.


Exterior View

11 Right Door Assembly



11.1: Rest Right Shed Door (119) with front side down, then slide Door End Channel (AG) onto the door.




11.2: Fit Thumb Lever Knobs into Handle Grooves.



11.3: Rotate the Thumb Lever into the handle. Slide forward until the Knobs fit into the holes in the handle.





11.4: Attach the Handle and Thumb Lever to the Door.



CAUTION
Do not overtighten. Overtightening may damage parts and void warranty.





11.5: Install Handle Latch assembly onto the Right Shed Door.



Hardware Bag: 1033168
Pliers
7/16" Wrenches (2)

You may need to nudge the Door End Channel to make the holes line up with the gap in the door.

11.6: Attach Door Spring (HD) to handle assembly. Set the door aside.




Hardware Bag: 1033072

Use pliers to pull spring down and hook into bottom hole.

11.7: Line up the hole in the Latch Block (XX) with the hole in the Thumb Lever (HG) and screw into place.


Note: The Spring is not shown in this illustration in order to better show the correct placement of the Latch Block.




The lip of the Latch Block (XX) fits under the Thumb Lever (HG).

15 Assemble Truss

15.1: Attach Brace (AC) to two Roof Truss Channels (AD) (one on each side of Brace). Secure Brace with Screws (TC) and Cap Nuts (HK).





Hardware Bag: 1033420 3/8" Wrench (1)




Follow picture above to connect Brace to a Truss Channel at each end of the Brace.

Use L-key (TD) to hold screw (TC) in place while tightening nut (HK).



The nut goes on outside of the truss.





WARNING
Do not over-tighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.

15.2: Use Truss Connector (TA) to attach Roof Truss Channels at top. Secure with Screws (TC) and Cap Nuts (HK). Before completely tightening, lay assembly on its side to be sure Channels and Brace are parallel. Completely tighten all hardware.



Be sure that Truss Connector is aligned with the Truss Channels.

WARNING
Do not over-tighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.




14 Assemble Rear Gable

14.1: Assemble two halves of the Rear Gable (112 & 113).





14.2: Install Vent (VA) and Screen (VB) into the Rear Gable. Set aside until later.



Second person should apply pressure on opposite side of the wall for easy insertion of screws.


12 Front Gable Assembly

12.1: Insert End Plugs (GB) into ends of Gable Support Header Bar (AH). Attach Gable Support Header Bar to Front Gable (111), and secure with Screws (GA).



The Square Tube must be oriented with the flat rectangle hole up, and the flat oval holes facing away from the gable.

12.2: Install Vent (VA) and Screen (VB) into the Front Gable, using Screws (PB) and Washers (VC).





Second person should apply pressure on opposite side of the wall for easy insertion of screws.


13 Install Doors and Front Gable

13.1: Slide Bushings (HU) underneath and through the holes of the Outer Floor Panel near the Left and Right Front Corner Panels.


13.2: Hang the Left and Right Doors over the Bushings near the Left and Right Front Corner Panels.



13.3: Slide the Cotter Pins (HS) through the Bushings and Hinges of both Doors.



You must align the two holes to insert the Cotter Pin.




After inserting the Cotter Pins, use pliers to bend the ends.

13.4: Install Front Gable.



One person should hold doors in place until they are secured with the front Gable.




Top Hinge pins fit into holes on underside of Front Gable



13.5: Secure both sides of Front Gable with Screws (SS).



Hardware Bag: 1001632 Screwdriver



PULL OUT THIS PAGE



Suggested Tools & Materials
(Not Included):

7/16"	3/8"	Adjustable	Rubber Mallet	Box Knife	Phillips Head
(2)	(1)	(1)	(1)	(1)	(1)
Step Ladder	Power Drill *	Work Light	Pliers	Flashlight	
(2)	(1)	(1)	(1)	(1)	

*See "Screwdriver Notice" on page 2

****U.S. and Canada customers ONLY****
IF ASSISTANCE IS NEEDED, DO NOT CONTACT THE STORE!!!
 CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865
 HOURS: 7:00 a.m. to 5:00 p.m. Monday through Friday (Mountain Standard Time)
 Call or visit our Web site for Saturday hours

For customers outside the U.S. or Canada, please contact the store for assistance.

PULL OUT THIS PAGE
FOR EASY REFERENCE