



Assembly Instructions

Norfolk Arbour

Code: 00505




CAUTION: CONSTRUCTION INVOLVES WORKING AT HEIGHT. SUITABLE EQUIPMENT REQUIRED.

(W x D x H) 1.56m x 0.67m x 1.99m



Online assembly video available

Please scan the QR code



PLEASE KEEP THESE INSTRUCTIONS

A guide to understanding the natural characteristics of timber and what to do if you feel there is an issue...

Timber is a unique and naturally beautiful material with its own characteristics which makes each piece distinctive.

At Zest we are committed to the environment and we are very proud to be a Forest Stewardship® Certified company. (FSC® C114990) and all timber used has been ethically sourced from responsibly managed forests.

Splits & cracks are to be expected in timber and they naturally appear in the grain due to changing temperatures and humidity levels. They are not a cause for concern as they will not affect the strength or durability of the product.



Normal splits are characteristics of timber.



Use the "2p Coin Test" as a guide.

If a particular split or crack becomes visible and is of concern simply use the "2p Coin Test" as a guide. There is no need for concern if the coin will not fit. If the coin does fit in the split, potentially there may be an issue. In this case, in order for customer services to investigate the matter fully, it should be reported in writing to your retailer, along with a clear photograph showing the 2p coin in place.

"Here at Zest we take any complaint very seriously and each one is investigated individually and judged specifically using established guidelines to determine if it is a justified complaint and whether a replacement part is required." *Customer Service Dept.*



Knots are characteristics of timber.



If you find a dead-knot email your retailer including a photo.

Sun Bleaching (from packaging) & **Green Spotting** (Caused by pressure treatment) are not causes for concern and they will fade over time when items are placed outdoors.



Neither will affect the durability of the product.

Sun-bleaching & Pressure Treatment green spotting will fade in time.

Knots are a natural characteristic of timber however a dead knot may be an issue which can be reported in writing to your retailer and must include photographic evidence to support the query.

IMPORTANT INFORMATION regarding further treatment: Pressure Treated products should not have any further treatment applied for the first 6 months



For Product Information

Norfolk Arbour Assembly Instructions

Requires 2 Person assembly

Tools required: Corded/Cordless Drill, *Pozi-drive bit/Screwdriver (*Crosshead), 3mm drill bit.
(All screw holes to be pre-drilled)

Please take a few moments to check all pack contents listed


Product Name Pack List		
Item	Description	Quantity
A	Side Panel	2
B	Front Panel	1
C	Rectangular Trellis Panel	1
D	Back Panel	2
E	Base Panel	1
F	Lid/Seat Assembly	1
G	Seat Back Assembly	1
H	Fascia	4
J	Roof Panel	2
K	Finial	2
L	Roof Capping	2
M	Triangular Trellis Panel	1

Fixings		Quantity
40mm Screws		11
50mm Screws		16
60mm Screws		30



This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase

1




Place Front Panel B between battens on Side Panels (A) (flush with outer edge of battens) and fix through Side Panels (A) using 4 x 60mm screws (2 x Screws per side).

2



Position Rectangular Trellis Panel (C) to rear posts of Side Panels (A) (flush with back and top of posts) and fix using 4 x 60mm screws (2 x per side).

3



Place 1 x Back Panel (D) directly beneath Rectangular Trellis Panel (C) and fix through posts using 4 x 60mm screws (2 x Screws per side). Place remaining Back Panel (D) beneath fixed Back Panel (D) and attach through posts using 4 x 60mm screws (2 x Screws per side).

4




Insert Base Panel (E) and fix using 4 x 40mm screws (1 x Screw per corner).

5




Position Lid/Seat Assembly (F) (lipped lid edge to front) onto upper battens of side panels and fix as shown using 4 x 60mm screws (2 x Screws per side).

6



Place Seat Back Assembly (G) onto fixed section of Lid/Seat Assembly (F) and fix in position using 4 x 60mm screws (2 x Screws per side).

7



Using Triangular Trellis Panel (M) as a guide, set out Roof Panels (J) and 2 x Fascia's (H) as shown.
Note: Ensure roof board overlaps are in correct orientation as to avoid rainwater ingress.

Attach Fascia's (H) to Roof Panels (J) using 6 x 50mm Screws (3 x Screws per Fascia).

8



Fix 1 x Finial (K) to Fascia's (H) using 2 x 50mm Screws.
Repeat Stage 8 for remaining Fascia's (H) and Finial (K) on other side of Roof Panels (J).

9



Join 2 x Roof Capping's (L) using 3 x 40mm Screws and attach to Roof Panels (J) using 4 x 40mm Screws (2 x Screws per end).

10



Fix Triangular Trellis Panel (M) to Rectangular Trellis Panel (C) using 2 x 60mm Screws.



Place roof assembly on to Side Panels (A) and Triangular Trellis Panel (M). Fix in position through Fascia's (H), into Side Panels (A) using 4 x 60mm Screws. (1 x Screw per Fascia (K)).

Norfolk Arbour is now complete.