

Overlap Apex Shed

4' x 3"

IMPORTANT, RETAIN FOR FUTURE REFERENCE; READ CAREFULLY

This buildings is pressure treated to ensure longevity of all timber components and to protect against rot. This may leave a colour difference on some parts that will even out as the moisture content stabilises. This will not need additional treatment.

- This product must be built on a solid level base.
- The roof of this building is not a load bearing structure.
- Please keep all plastic bags and small parts away from children.
- Due to the nature of the material the doors may need some trimming for a neater fit.
- Timber is a natural material. It will shrink and swell as a result of varying moisture content.

Technical Helpline: **0333 7777 089** 8.30 am and 5.00 pm Monday to Friday.


Please check all parts prior to assembly

Assembly of damaged parts may be deemed to be acceptance and this may affect the remedies you are entitled to. If the product is not constructed in accordance with the instructions, or is altered in any way (e.g. painted), the manufacturer cannot be held liable for any resulting damage.

Fixing Pack (OPA43FP)

Not to Scale


This fixing pack is used for several products. There may be additional fixings.



Hasp & Staple



10mm Felt tacks Qty 60



Flush Hinge Qty 2




40mm Screw Qty 12



30mm Screw Qty 17



50mm Screw Qty 22



30mm Nail Qty 36




25mm Screw Qty 17

REQUIRED TOOLS : (NOT SUPPLIED)



SHARP KNIFE



SPIRIT LEVEL



POZI DRIVE SCREWDRIVER



TAPE MEASURE



HAMMER


Important : Assembly of this shed requires a minimum of two adults.



Must Pre drill for each screw used.


OPA43 PARTS LIST

A



OPA4DE DOOR END

B




OPA4PE PLAIN END

C




OPA3PS PLAIN SIDE QTY 2

D



BRDFL43 FLOOR

E



SDRPT DOOR

F



8987658 ROOF SHEET QTY 2

G




FIN20010512PT FINIAL QTY 1

H



45280866PT 866mm BATTEN QTY 1

I



51120810PAII58PT 810mm BARGE BOARD QTY 4

J



44121570PT 1570mm C/STRIP QTY 4

K



28280898PT 898mm BATTEN QTY 2

L




20121695PPT 20 x1695mm STRIP QTY 1



FELT

85062 Qty 1


1



Place the panels on top of the floor. Make sure that all of the panels are tight and flush before fixing them to each other using 3x50mm screws.


Make sure that the panels are sitting flush before fixing to the floor using 2 x 50mm screws for each panel. Make sure that all of the screws are positioned so that they screw in to the bearers underneath.

3



Place the corner strips so that they cover the joints between the panels. Fix each in place using 3 x 30mm screws


2



a Fix the 20 x 1695mm strip to the side of the door frame so that it is tight with the cladding and flush with the frame. Use 3 x 30mm screws.


b Place the hinge against the inside of the door frame and position the large section of the hinge so that it is with the inside of the framing as shown and fix with 25mm screws. Open the hinge and fix the smaller section to the door framing. Again make sure that the hinge is flush and that the holes are positioned so that the 25mm screws locate correctly into the batten.

4



Place the 866mm batten so that it connects the door end and plain end. Fix this in position using a 50mm screw for each end as shown.


5



Place the roof board on to one of the 898mm battens. Make sure that the board is flush on all sides.

Fix each batten in place using 30mm nails spaced in 300mm intervals. (Repeat for the other roof section)



6



Lift the roof sections in to place making sure that they are in line with the apex and the door and plain ends.

Fix the roof in place using 30mm nails spaced in approximately 300mm intervals. (Make sure the nails locate into the framework of the panels)


7



Attention
Take care when cutting and trimming the roof felt.


Unroll the felt and cut it in to two equal lengths. Place the sheets on each side so that there is a 50mm overhang on the eaves and they overlap at the apex. Fix these to the roof using felt nails spaced in 150mm intervals. Cut and fold the corners securing with a single felt nail for each.

8



Place the barge boards against the front and back of the shed. Make sure that these are in line with the roof sheet and meet at the apex. Fix each in place using 3 x 40mm screws.
Place a finial over the top of where the barge boards meet and fix it in place using 2 x 30mm screws.

9



Place the hinge against the inside of the door frame and position the large section of the hinge so that it is flush with the inside of the framing as shown. Fix with 25mm screws.

Open the hinge and fix the smaller section to the door framing. Again make sure that the hinge is flush and that the holes are positioned so that the 25mm screws locate correctly into the batten.

Biocidal Product Regulation (EU 528/2012) Article 58 Information

This article contains timber treated with Celcure AC-500, incorporating biocidal products to give protection against wood destroying insects & wood rotting fungi.

Contains: Basic copper carbonate (Copper (II) carbonate – Copper (II) hydroxide (1:1)), Boric acid, Benzalkonium chloride.

Wear gloves when handling freshly treated wood. Avoid breathing dust when cutting treated or untreated wood. Dispose of off-cuts responsibly – do not burn.

Maintenance.

Regularly check all fixings are secure and the roofing felt has no holes or tears.

Sand off any rough/sharp edges.