



Assembly Instructions

Santorini Swing

Code: 20772




CAUTION: CONSTRUCTION INVOLVES WORKING AT HEIGHT. SUITABLE EQUIPMENT REQUIRED.

(W x D x H) 1.90m x 1.50m x 1.80m



Online assembly video available

Please scan the QR code




PLEASE KEEP THESE INSTRUCTIONS

A guide to understanding the natural characteristics of timber and what to do if you feel there is an issue...

Timber is a unique and naturally beautiful material with its own characteristics which makes each piece distinctive.

At Zest we are committed to the environment and we are very proud to be a Forest Stewardship® Certified company. (FSC® C114990) and all timber used has been ethically sourced from responsibly managed forests.

Splits & cracks are to be expected in timber and they naturally appear in the grain due to changing temperatures and humidity levels. They are not a cause for concern as they will not affect the strength or durability of the product.



Normal splits are characteristics of timber.



Use the "2p Coin Test" as a guide.

If a particular split or crack becomes visible and is of concern simply use the "2p Coin Test" as a guide. There is no need for concern if the coin will not fit. If the coin does fit in the split, potentially there may be an issue. In this case, in order for customer services to investigate the matter fully, it should be reported in writing to your retailer, along with a clear photograph showing the 2p coin in place.

"Here at Zest we take any complaint very seriously and each one is investigated individually and judged specifically using established guidelines to determine if it is a justified complaint and whether a replacement part is required." *Customer Service Dept.*



Knots are characteristics of timber.



If you find a dead-knot email your retailer including a photo.

Sun Bleaching (from packaging) & **Green Spotting** (Caused by pressure treatment) are not causes for concern and they will fade over time when items are placed outdoors.



Neither will affect the durability of the product.



Sun-bleaching & Pressure Treatment green spotting will fade in time.

Knots are a natural characteristic of timber however a dead knot may be an issue which can be reported in writing to your retailer and must include photographic evidence to support the query.

IMPORTANT INFORMATION regarding further treatment: Pressure Treated products should not have any further treatment applied for the first 6 months



For Product Information

Santorini Swing Assembly Instructions

Requires 2 Person assembly

Tools required: Corded / cordless drill, *Pozi- drive bit or Pozi-drive screwdriver (*Crosshead), Socket set (13mm, 17mm & 19mm), Hammer and Mallet. Star Drive included.

Please take a few moments to check all pack contents listed

Santorini Swing Pack List		
Item	Description	Quantity
A	Horizontal Long Brace	2
B1, B2	Lower Leg (front)	2
C1, C2	Leg (back)	2
D	Horizontal Short Brace	2
E1, E2	Upper Leg (front)	2
F	Trellis Panel	2
G	Swing Beam	1
H	Diagonal Brace	2
J	Canopy Support	2
K	Canopy	1
L	Centre Batten	1
M	Seat Back	1
N	Seat	1
O	Armrest Support	2
P1, P2	Armrest	2
Q	Shelves	2
R	Fixing Kit	1





This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase

Santorini Swing Assembly Instructions

Fixings	Quantity
30mm Screw	16
60mm Screw	42
80mm Screw	2
45mm Bolt, washer & nut	6
90mm Bolt, washer & nut	4
100mm Bolt, washer & nut	22
115mm Eye Bolt &, washer & nut	2
140mm Eye Bolt, washer & nut	2
170mm Eye Bolt & washer & nut	2
Small karabiner	6
Large karabiner	2
700mm Chain	2
900mm Chain	2
100mm Star Screw Drive	1

1



Set out Lower Leg (front) (B1), Upper Leg (front) (E1) and Leg (back) (C1) as shown (left) (large holes face down) and place Horizontal Long Brace (A) and Horizontal Short Brace (D) in position shown (Above left) Align bolt holes and insert 8 x 100mm Bolts. (Nuts & washers to be attached at a later stage).

Note: horizontal short brace D has offset central hole which should be positioned closest to rear leg C1.

Position Trellis Panel (F) between horizontal bracings and attach to Lower Leg (front) (B1) and Leg (back) (C1) using 4 x 60mm screws.



Repeat procedure for remaining Lower Leg (front) (B2), Leg Back (C2), Upper Leg front (E2), Horizontal Long Brace (A), Horizontal Short Brace (D) and Trellis Panel (F) to form right hand side of swing.

2



Ensuring large drilled holes are facing up, attach Swing Beam (G) to Back Leg (C1) using 1 x 100mm Bolt, Nut & Washer. Do not fully tighten at this stage.

3



Attach Diagonal Brace (H) to Swing Beam (G) using 2 x 90mm Bolts, Nuts & Washers, and to Horizontal Short Brace (D) using 1 x 100mm Bolt, Nut & Washer.

4




Attach other end of Swing Beam G to Back Leg C2 on previously assembled right hand side of swing using 1 x 100mm Bolt, Nut & Washer.

5



Attach remaining Diagonal Brace (H) to Swing Beam (G) using 2 x 90mm Bolts, Nuts & Washers, and to Horizontal Short Brace (D) using 1 x 100mm Bolt, Nut & Washer.


6



Ensuring Upper Legs (front) E1 & E2 are flush with underside of Swing Beam (G) (See above), fix to Legs (back) C1, C2 as shown using 2 x 100mm Star Screws. (1 x Screw per leg).



All Nuts & Washers from Stage 1 onwards to be attached and fully tightened at this stage.

7




Attach Canopy Support (J) to Leg (back) (C1) using 1 x 100mm Bolt, Nut & Washer. Set at desired angle and fix to Swing Beam (G) using 1 x 80mm Screw.

8




Insert 170mm Eye-Bolt into Swing Beam (G) as shown. Attach Washer & Nut and fully tighten. Repeat procedure with remaining 170mm Eye-Bolt on other side of swing.



Set Canopy (K) out evenly on to Canopy Supports (J) and fix using 32 x 60mm Screws (2 x Screws per slat, 1 x Screw at each end).


9



Insert Centre Batten (L) centrally beneath Canopy (K) and fix using 16 x 30mm Screws. (1 x Screw per slat), working from front to back.



Note: Seat Back (M) on left. Seat (N) on right.



Interlock joints in Seat Back (M) and Seat (N), align bolt holes and secure using 6 x 45mm Bolts, Nuts & Washers. (2 x Bolts per joint) do not tighten fully at this stage.

11



Align dowels in Armrest Support (O) with corresponding holes in Armrest (P1) and tap into position. Fix in place using 1 x 60mm Screw.

12



Place Armrest Assembly on to Seat Assembly, align bolt holes and insert 1 x 140mm Eye Bolt into Seat Back (M) and 1 x 115mm Eye Bolt into Seat (N). Attach Nuts & Washers and fully tighten.


**Repeat Stage 11 for remaining armrest assembly on other side of seat assembly.
Fully tighten all nuts at this stage.**



Using 2 x Small Karabiners (1 x Per Eye Bolt), attach 1 x Short chain to rear Eye-Bolt and 1 x Long chain to front Eye-Bolt. Repeat procedure on other side of seat.



Feed the long front chains through the holes in the Armrest Assemblies and attach pairs of chains (long and short) to Small Karabiners and clip to Large Karabiners on Swing Beam Eye Bolts.



Place Shelves (Q) on to Horizontal Short Braces (D). Tap in with a mallet to fit.

Santorini Swing is now complete.