

UK SET UP INSTRUCTIONS

3705 - THREE TIER SPADE FOUNTAIN

Open bag containing the pump kit **UK110008**. In the kit you will find:

1 – PUMP 1100 (12v AC, 50Hz)	1 – 2-hole rubber stopper	1 – hose clamp
1 - 3/4" clear tubing 36" long	1 - tube of silicone	

1. Place pedestal on a firm and level surface where fountain will remain. Place the largest shell on the pedestal.
2. Find the pump and the 2-hole rubber stopper. Place the pump into the pump house located in center of the largest shell and run the plug end of the electrical cord down the PVC pipe located in the pump house and down into the pedestal. Retrieve cord from under the shell and place in groove on top of the pedestal. Slip the rubber stopper onto the power cord about 12" from the pump. Insert the rubber stopper snugly into the PVC pipe. **To make a water tight seal, apply silicone in the hole and around the wire that is in the rubber stopper.**
3. Position the largest shell on pedestal and level. To level shell, place level on the top rim of the pump house in the center of shell. Level in (2) Two directions left to right and front to back. **Shim as needed.**
4. Find the piece of 3/4" clear tubing 36" long and connect one end to the outlet of the pump with the hose clamp. Find the second shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position the shell on top of pump house in center of large shell and level as stated in step #3.
5. Find the third shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position the third shell on top of the second shell and level. To level shell, place level on the center housing of the shell. Level as stated in step #3.
6. Cut the 3/4" clear tubing 10" above the top surface of the center housing on the third shell. Find the finial. In the center of the finial you will see a PVC pipe. Insert the 3/4" clear tubing into the PVC pipe in the bottom of the finial and slide the finial down onto the center housing of the second shell. Position the finial on the fountain.
7. Find the drain plugs and insert snugly into the drain inserts located in the two shells of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug.
8. Fill the shells with water. Connect the power cord on the pump to the transformer. Plug the transformer into a 240VAC RCD protected mains outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.
9. How to apply the clear silicone. The fountain must be dry. Apply about a 1/2" line of silicone on the tip of your index finger. On the very bottom of the drip edges, where the water drips from the bowl, touch your index finger to the drip edges and pull straight down. This will leave a dab of silicone on the very bottom of the drip edge to break the film of the water and allow the fountain to drip straight down.