

## UK SET UP INSTRUCTIONS

### 3870 30" CHELSEA FLEUR DE LIS FLUTED FOUNTAIN

Open bag containing the pump kit **UK45004**. In the kit you will find:

1 – PUMP 450 (12v AC, 50Hz)	1 – 2-hole rubber stopper	1 – clear nozzle kit
1 - 1/2" kink free tubing 4" long	1 - hose clamp	1 – tube of silicone

1. Place the pedestal on a firm and level surface where fountain will remain. Place the shell on the pedestal.
2. Find the pump and the 2-hole rubber stopper. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. **Position the rubber stopper about 7" from the body of the pump.** Place pump in the pump house in center of the shell and run the plug end of the electrical cord down the hole located in the center of the pump house and down through the pedestal. Retrieve cord from under pedestal and place in the groove in the bottom of pedestal. Insert the rubber stopper snugly into the hole. **To make a water tight seal, apply silicone in the hole and around the wire that is in the rubber stopper. Apply more silicone around the outside edge and on top of the rubber stopper.** Position the shell on the pedestal and level. To level shell, place level on the top rim of the shell. Level in all directions. **Shim as needed.**
3. Find the piece of 1/2" kink free tubing 4" long and hose clamp. Attach the piece of 1/2" kink free tubing 4" long onto the outlet side of the pump with a hose clamp. **Adjust the dial type flow control located on the front of the pump to the lowest position.**
4. Find the finial. In the base of the finial you will see a copper pipe. Remove any excess concrete or tape from both ends of this copper pipe.
5. Attach the piece of 1/2" kink free tubing to the copper pipe located in the base of the finial. Position the finial in the center of shell.
6. Find the clear nozzle kit. Slip the clear nozzle onto the copper pipe that is on top of the finial. If needed apply a small amount of clear silicone (not supplied) around the copper pipe that is on the top of the finial before you slip on the clear nozzle.
7. Fill the shell with water. Connect the power cord on the pump to the transformer. Plug the transformer into a 240vac RCD protected mains outlet. Adjust the water flow to the finial using the built in flow control dial on the front of the pump.