

6' x 8' Overlap Apex Shed

IMPORTANT, RETAIN FOR FUTURE REFERENCE; READ CAREFULLY

This building is pre-treated with a factory base coat for protection during storage and transit. We recommend that you treat your new building as soon as possible after assembly using a wood preservative treatment. Apply in accordance with the manufacturers instructions.

- This product must be built on a solid level base.
- The roof of this building is not a load bearing structure.
- Timber is a natural material. It will shrink and swell as a result of varying moisture content.
- Due to the nature of the material the doors may need some trimming for a neater fit.
- Please keep all plastic bags and small parts away from children

Technical Helpline: **0333 7777 089** 8.30 am and 5.00 pm Monday to Friday.


Please check all parts prior to assembly

Assembly of damaged parts may be deemed to be acceptance and this may affect the remedies you are entitled to. If the product is not constructed in accordance with the instructions, or is altered in any way (e.g. painted), the manufacturer cannot be held liable for any resulting damage.


Fixing Pack (ODA68FP)

This fixing pack is used for several products. There may be additional fixings.


Not to Scale



Hasp & Staple



L' bracket Qty 6



Flush Hinge Qty 2




30mm Screw Qty 2



50mm Screw Qty 22




25mm Screw Qty 53



30mm Nail Qty 40



20mm Nail Qty 16




25mm Security Screws Qty 12



10mm Felt tacks Qty 100

REQUIRED TOOLS : (NOT SUPPLIED)




Important : Assembly of this shed requires a minimum of two adults.




ODA68NW PARTS LIST

A




ODA6DE DOOR END

B




EOL68PE PLAIN END

C




EOLPP2275 PLAIN PANEL QTY 2

D



SFL46 FLOOR QTY 2

F



SDRDT DOOR

F




236510708 ROOF BOARD QTY 2

G




9090012FINDTR FINIAL QTY 2

H



28121183P 1183mm BATTEN QTY 2

I



45282331PAR 2331mm BATTEN QTY 1

J




44161490DTR 1490mm Corner STRIP QTY 4

K



40081085DTR 1085mm BARGE BOARD QTY 4

L



20121695P 1695mm STRIP QTY 1



FELT FELT78BL QTY 1

1

Turn the floor sections upside down and secure them to each other screwing through the bearers using 2 x 50mm screws.

Turn the floor back over once its completed.

2

Place the panels on top of the floor. Make sure that all the panels are tight and flush before fixing them to each other using 3x50mm screws.

When the panels are secured to each other, make sure that they are square before securing them to the floor. Use with 3 x 50mm screws for each of the side panels and the door end, making sure these locate into the floor bearer. Fix the plain end to the floor using 2 x L' brackets and 8 x 25mm screws as illustrated.

(when positioning the brackets make sure these are in line with the floor bearers underneath.)

3

Fix the 20 x 1695mm strip to the side of the door frame so that it is tight with the cladding and flush with the frame. Use 4 x 30mm nails.

4

Place the hinge against the inside of the door frame and position the large section of the hinge so that it is flush with the inside of the framing as shown. Fix with 25mm screws.


Open the hinge and fix the smaller section to the door framing. Again make sure that the hinge is flush and that the holes are positioned so that the 25mm screws locate correctly into the batten.

5

Place the 2331mm batten so that it sits at the apex and bridges between the plain end and door end. Fix the batten in place using an L' bracket and 4 x 25mm screws for each end.

Position each corner strip so that it is flush with the panel and covers the joins. Fix each in place using 4 x 30mm nails.


6



Place the roof board onto the 1183mm battens making sure that the board is flush on all sides. Fix each batten in place using 4 x 20mm nails.

Repeat for the other roof section.

7




Lift the roof sections into place making sure that they are in line with the apex and the front and back panels of the shed.

Fix the roof section in place using 3 x 25mm screws for each and 1 x 30mm screw for the sides. Make sure the screw locate into the framing.

Repeat for the other roof section.


8



Unroll the felt and cut it into three equal lengths. Place a section on each eaves so that there is a 50mm overhang on each edge as shown. Fix this to the roof using felt nails spaced in 150mm intervals. Cut and fold the corners securing with a single felt nail for each.

Place the remaining section as shown making sure that the it overlaps the others. Again secure each sheet in place using felt nails spaced in 150mm intervals.

9




Attention
Take care when cutting and trimming the roof felt.

Place the barge boards against the ends of the shed so that they are flush with the overhang of the roof and in line with the top. Fix each in place using 4x30mm nails.

Place the finials over the join making sure that they are centred. Secure in place using 2x30mm nails for each.

Trim off any excess felt using a sharp knife.

10



Before fixing the Hasp to the door make sure that it is in line with the framing on the reverse and is positioned so that it will close over the Staple. Fix this in place using 3 x 25mm screws.

Position the Staple opposite, again making sure that it is in line with the framing behind and fix it in place using 2 x 25mm screws.

Biocidal Product Regulation (EU 528/2012) Article 58 Information

This article contains timber treated with Celcure AC-500, incorporating biocidal products to give protection against wood destroying insects & wood rotting fungi.

Contains: Basic copper carbonate (Copper (II) carbonate – Copper (II) hydroxide (1:1)), Boric acid, Benzalkonium chloride.

Wear gloves when handling freshly treated wood. Avoid breathing dust when cutting treated or untreated wood. Dispose of off-cuts responsibly – do not burn.

Maintenance.

We recommend that you treat your shed at the beginning of each season with a wood preservative treatment. Apply in accordance with the manufacturers instructions.

Regularly check all fixings are secure.