

# Sorrento Corner Arbour

IMPORTANT: RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.

- Always pre-drill timber to avoid splitting.
- The timber in this product is pressure treated to ensure longevity and protection against rot.
- This may leave colour variations, but these will even out as the moisture content stabilises.
- Timber is a natural material and will shrink and swell as a result of varying moisture content.
- Keep all plastic bags and parts away from children.
- This product is not intended for use by children. Please make sure children are supervised at all times.
- The roof of this product is not load bearing.

Technical Help line: 0333 7777 089 8.30am - 5.00pm Monday to Friday

In line with your statutory rights, please check all parts prior to assembly, as assembly of damaged parts may be deemed to be acceptance and this may affect

This article contains biocidal products to give protection against wood destroying insects & wood rotting fungi. Contents may vary.  
 May contain: Basic copper carbonate (Copper (II) carbonate - Copper (II) hydroxide (1:1)), Cupric oxide, Copper hydroxide carbonate, oxyethyl, ammoniumpropionate, Copper HDO, Propiconazole, Tebuconazole, Boric acid, Benzalkonium chloride.  
 Wear gloves when handling freshly treated wood. Avoid breathing dust when cutting treated or untreated wood. Dispose of off-cuts responsibly - do not burn.




**Important: Assembly of this Arbour requires two adults**




REQUIRED TOOLS: (NOT SUPPLIED)




PARTS:




Fix the leg (part K) to the bottom of the large bench section as shown with 2 x 60mm screws. Place the bench against the side sections as shown, making sure that the post with the double notch at the top is positioned as shown. Place the bench so that it is 400mm above the ground level and fix in place by screwing through the bench support framework into the post of part A and post and trellis of part B.




Place the smaller bench seat against the panel as shown again making sure it is 400mm from the ground level. Fix using 4x60mm screws. Place both sections of the arbour together and fix the small section to the leg using 2x60mm screws as shown.




Slot the bench backs into position. These slot into the notches on the bench seats as shown. Fix each with 2x30mm screws. Screw through the ends of the bench into the other using a 60mm screw for each bench batten.



Position the trellis assembly with the single post so that the post will be against the framing of the bench as shown. Fix in place using 3x60mm screws to secure the trellis to the opposite post and also secure the bench seat and bench backs to the posts using a 60mm screw for each of the bench battens.



Position the rafters so they sit into the notches on the posts as shown. secure these in place by screwing through each post using 2x60mm screws. Where the shorter rafters meet the large rafters, fix these in place by screwing through the large rafter into the end of the shorter.



Place the small notched rafters on to the top of the arbour. Secure each in place using a 60mm screw for each end.