



Assembly Instructions

TENBY ARBOUR

Code: CODE: 25222




CAUTION: CONSTRUCTION INVOLVES WORKING AT HEIGHT. SUITABLE EQUIPMENT REQUIRED.

(W x D x H) 2.07m x 0.85m x 2.07m



Online assembly video available

Please scan the QR code or visit zest4leisuresupport.co.uk



PLEASE KEEP THESE INSTRUCTIONS

A guide to understanding the natural characteristics of timber and what to do if you feel there is an issue...

Timber is a unique and naturally beautiful material with its own characteristics which makes each piece distinctive.

At Zest we are committed to the environment and we are very proud to be a Forest Stewardship® Certified company. (FSC® C114990) and all timber used has been ethically sourced from responsibly managed forests.

Splits & cracks are to be expected in timber and they naturally appear in the grain due to changing temperatures and humidity levels. They are not a cause for concern as they will not affect the strength or durability of the product.



Normal splits are characteristics of timber.



Use the "2p Coin Test" as a guide.

If a particular split or crack becomes visible and is of concern simply use the "2p Coin Test" as a guide. There is no need for concern if the coin will not fit. If the coin does fit in the split, potentially there may be an issue. In this case, in order for customer services to investigate the matter fully, it should be reported in writing to your retailer, along with a clear photograph showing the 2p coin in place.

"Here at Zest we take any complaint very seriously and each one is investigated individually and judged specifically using established guidelines to determine if it is a justified complaint and whether a replacement part is required." *Customer Service Dept.*




Knots are characteristics of timber.



If you find a dead-knot email your retailer including a photo.

Sun Bleaching
(from packaging)
& Green Spotting
(Caused by pressure treatment) are not causes for concern and they will fade over time when items are placed outdoors.

Neither will affect the durability of the product.



Sun-bleaching & Pressure Treatment green spotting will fade in time.

Knots are a natural characteristic of timber however a dead knot may be an issue which can be reported in writing to your retailer and must include photographic evidence to support the query.

IMPORTANT INFORMATION regarding further treatment: **Pressure Treated products should not have any further treatment applied for the first 6 months**



For Product Information

Product Assembly Instructions


Requires: 2 person assembly.

Tools required: Corded / cordless drill, 3 mm drill bit as all screw holes need to be predrilled, Pozi drive bit / Screwdriver (*Crosshead)

Please take a few moments to check all pack contents listed



| Product Name Pack List | | |
|------------------------|--------------|----------|
| Item | Description | Quantity |
| A | SEAT BACK | 1 |
| B | SEAT | 1 |
| C1, C2 | SIDE PANELS | 2 |
| D | BACK PANELS | 2 |
| E | ROOF PANELS | 2 |
| F | ROOF SUPPORT | 1 |
| G | ROOF CAPPING | 1 |
| H | FASCIAS | 4 |
| J | FINIALS | 2 |

| Fixings | Quantity |
|----------------------------|----------|
| 35mm Screws | 12 |
| 40mm Screws | 8 |
| 50mm Screws | 20 |
| 60mm Screws | 4 |
| 45mm Bolts, nuts & washers | 6 |
| 90mm Bolts, nuts & washers | 6 |





This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase

1



Interlock joints in Seat Back (A) with Seat (B) as shown in Fig. 1 and secure using 6x 45mm bolts, nuts & washers. (2x 45mm bolts per joint).

2



Align bolt holes in Side Panel (C1) and seat assembly and attach using 3x 90mm bolts, nuts & washers. Repeat procedure for Side Panel (C2). (See Fig. 2b).


Note Grooves in rear of side panels should be facing inwards.

3



Position 1x Back Panel (D) in to base of block stopper in side panels and fix using 4x 40mm screws (2x screws per side).

4




Position remaining Back Panel (D) as shown in Fig. 4 and attach using 4x 40mm screws (2x 40mm screws per side)

5




Attach 1x Roof Panel (E) to Roof Support (F) using 2x 60mm screws as shown in Figs. 5a & 5b.

Note: Ensure roof board overlap are in correct orientation as to avoid rainwater ingress.



Attach remaining Roof Panel (E) using 2x 60mm screws as shown in Fig. 5c (1x 60mm screw at each end).




6



Fix Roof Capping (G) to Roof Panels (E) using 4x 35mm screws (2x 35mm at each end)

Note: Do not lay the roof flat on the apex at this point.

7





Set out 2x Fascia (H) as shown and attach to roof assembly using 6x50mm screws (3x 50mm screws per fascia).

Position Finial (J) as shown and attach using 4x 35mm screws.

Repeat procedure for remaining Fascia (H) and Finial (J) on opposite side of roof assembly.

8



Locate roof assembly onto Side P anel (C1 & C2) posts and fix in position using 8x 50mm screws (2x 50mm screws per post).

9



The Tenby Arbour is now complete.